

**Montageanleitung**

**Freilaufende Radiallaufräder  
/ Einbauventilatoren**


direktgetrieben, mit IEC-Normmotor der Schutzart druckfeste Kapselung Ex de IIC T4 Gb oder druckfeste Kapselführung mit Klemmkasten erhöhte Sicherheit Ex de IIC T4 Gb für die Förderung von explosionsfähiger Atmosphäre der Zone 1 Kategorie 2G und Zone 2 Kategorie 3G.


**Inhaltsübersicht**

Kapitel	Seite
Anwendung . . . . .	1
Sicherheitshinweise . . . . .	2
Transport, Lagerung . . . . .	3
Laufradeinbau . . . . .	3
Elektrischer Anschluss . . . . .	4
Geräteaufstellung . . . . .	4
Betriebsbedingungen . . . . .	5
Inbetriebnahme . . . . .	5
Instandhaltung und Wartung . . . . .	6
Reinigung . . . . .	6
Hersteller . . . . .	7
Serviceadresse . . . . .	7

**VENTILATOR-Typenschild  
einkleben!**

Die Einhaltung der nachfolgenden Vorgaben dient auch der Sicherheit des Produktes. Sollten die angegebenen Hinweise insbesondere zur generellen Sicherheit, Transport, Lagerung, Montage, Betriebsbedingungen, Inbetriebnahme, Instandhaltung, Wartung, Reinigung und Entsorgung / Recycling nicht beachtet werden, kann das Produkt eventuell nicht sicher betrieben werden und kann eine Gefahr für Leib und Leben der Benutzer und dritter Personen darstellen.  
Abweichungen von den nachfolgenden Vorgaben können daher sowohl zum Verlust der gesetzlichen Sachmängelhaftungsrechte führen als auch zu einer Haftung des Käufers für das durch die Abweichung von den Vorgaben unsicher gewordene Produkt


**Anwendung**
**RH..C**

KL. 1757

- ZIEHL-ABEGG - Freilaufende Radiallaufräder der Baureihe **RH..C**, in den lieferbaren Baugrößen **250 bis 1000**, sowie die Gerätebaureihe **ER..C** (Typenbezeichnung siehe Typenschild) in explosionsgeschützter Ausführung **Ex II 2G c IIB T4 mit IEC-Normmotor der Zünd-**

**Assembly instructions**

**Centrifugal impeller without scroll / Plenum Fans**


*direct-driven, with IEC standard motor of protection type pressure-proof housing Ex de IIC T4 Gb or pressure-proof housing with terminal box for increased safety Ex de IIC T4 Gb for conveyance of zone 1 category 2G and zone 2 category 3G explosive atmospheres.*


**Contents**

Chapter	Page
Application . . . . .	1
Safety instructions . . . . .	2
Transport, storage . . . . .	3
Installing the impeller . . . . .	3
Electrical connection . . . . .	4
Setting up the unit . . . . .	4
Operating conditions . . . . .	5
Start-up . . . . .	5
Repairs and maintenance . . . . .	6
Cleaning . . . . .	6
Manufacturer: . . . . .	7
Service address . . . . .	7

*Compliance with the following instructions is mandatory to ensure the functionality and safety of the product. If the following instructions given especially but not limited for general safety, transport, storage, mounting, operating conditions, start-up, maintenance, repair, cleaning and disposal/recycling are not observed, the product may not operate safely and may cause a hazard to the life and limb of users and third parties.*

*Deviations from the following requirements may therefore lead both to the loss of the statutory material defect liability rights and to the liability of the buyer for the product that has become unsafe due to the deviation from the specifications.*


**Application**
**ER..C**

KL. 1760

- ZIEHL-ABEGG - Series **RH..C** free running centrifugal impeller, available in frame sizes **250 to 1000**, and the device series **ER..C** (Type designation see rating plate) in explosion-proof version **Ex II 2G c IIB T4 with IEC standard motor protection type Ex de IIC T4 Gb or Ex d IIC T4 Gb** are not ready-for-use products, but are designed

**schutzart Ex de IIC T4 Gb oder Ex d IIC T4 Gb** sind keine gebrauchsfertigen Produkte, sondern als Komponenten für Klima-, Be- und Entlüftungsanlagen konzipiert. Sie dürfen erst betrieben werden, wenn sie ihrer Bestimmung entsprechend eingebaut sind und die Sicherheit durch Schutzeinrichtungen nach DIN EN ISO 13857 / EN 60529 und die nach EN 14986 erforderlichen baulichen Explosionsschutzmaßnahmen sichergestellt ist.

- Der Anlagenbauer ist für die Abdichtung der Anlage verantwortlich.
- Die Ventilatoren erfüllen hinsichtlich der Werkstoffwahl durch besondere Schutzmaßnahmen im Bereich möglicher Berührungsflächen zwischen rotierenden und stehenden Bauteilen (Lüfterraddeckscheibe / Einströmdüse) die Anforderungen der Norm EN14986. Für das rotierende Teil (Lüfterraddeckscheibe) wird als Werkstoff „Stahl beschichtet“ eingesetzt. Für die Auswahl des Werkstoffs der feststehenden Peripherieteile ist, bei Bezug des Lüfterrades ohne ZIEHL-ABEGG-Einströmdüse, der Anlagenbauer verantwortlich. Es dürfen nur Werkstoffpaarungen nach EN 14986 eingesetzt werden.



## Safety instructions

- The impellers are only intended for the conveyance of air or zone 1 category 2G and zone 2 category 3G explosive atmospheres. The conveyance of solid matter or solids content in the conveyance medium handled is not permitted.
- Only operate the fan according to the intended application, and only up to the **maximum permissible speed** given in the information on the fan/impeller rating plate. Exceeding the maximum permissible speed leads, as a result of the high kinetic energy (mass x rotation rate), to a hazardous situation. **The impeller can burst - lethal hazard!** The maximum permissible operating data given on the rating plate is valid at an air density  $\rho = 1.2 \text{ kg/m}^3$ .
- Impellers without housing/plug fans as well as the **ER...** device series may only then be operated with a frequency converter if a drive motor of the "**Ex de IIC or Ex d IIC pressure-proof housing**" ignition protection type is utilized.
- The data concerning the temperature class on the EX-rating plate (motor) must coincide with the temperature class of any possibly occurring combustible gasses.
- Mounting and electrical installation may only be carried out by trained specialized personnel who observe the **relevant regulations!**
- A protective motor switch must be connected before each motor. Please comply with the motor manufacturer's instructions.
- Winding monitoring through PTC thermistors for disconnection at the converter. A triggering device with the II (2) G mark is needed as a safeguard.
- In case of speed control through a frequency converter, it must be ensured that the max. permissible speed cannot be exceeded due to any frequency converter malfunction.
- When in operation with a frequency converter, no over-modulation is allowed. The fan wheel may burst – **danger to life!**
- With regard to speed regulation with frequency converters, the safety instructions and recommendations are to be maintained in accordance with the motor manufacturer's operating instructions. This also applies to motor installation, electrical connections, and servicing.
- Observe the installation and safety instructions applicable to the various fan designs. Non-observance or misuse can lead to bodily harm or damage to the fan and to the explosion of ignitable gas-air mixtures - **Danger of death.**
- Observe the notes in the motor manufacturer's operating instructions, which form part of the supply.
- If a fan is utilized as a free inlet or free discharge type, verify that the required clearance based on **DIN EN ISO 13857 / EN 60529** is maintained.
- The maintenance of the standard DIN EN ISO 13857 / EN 60529 relates only to the installed accidental contact protection, provided that it is part of the scope of delivery.
- Pay special attention that there is sufficiently dimensioned safety clearance on the inlet side, as clothes, limbs, or, in the case of large fans, even people can be sucked in due to the fan's suction power.



## Sicherheitshinweise

- Die Laufräder sind nur zur Förderung von Luft oder explosionsfähiger Atmosphäre der Zone 1 Kategorie 2G und Zone 2 Kategorie 3G bestimmt. Die Förderung von Feststoffen oder Feststoffanteilen im Fördermedium ist nicht zulässig.
- Betreiben Sie den Ventilator nur nach seiner bestimmungsgemäßen Verwendung und nur bis zur **max. zulässigen Betriebsdrehzahl** gemäß Angaben auf dem Ventilator-/Laufrad-Typenschild. Ein Überschreiten der max. zul. Betriebsdrehzahl führt als Folge der hohen kinetischen Energie (Masse x Drehzahl) zu einer Gefährdungssituation. **Das Laufrad kann bersten - Lebensgefahr!** Die max. zulässigen Betriebsdaten auf dem Typenschild gelten für eine Luftdichte  $\rho = 1,2 \text{ kg/m}^3$ .
- Freilaufende Laufräder sowie die Gerätebaureihe **ER...** dürfen mit Frequenzumrichter nur dann betrieben werden, wenn ein Antriebsmotor der Zündschutzart „**Druckfeste Kapselung Ex de IIC oder Ex d IIC**“ verwendet wird.
- Die Angabe der Temperaturklasse auf dem EX-Prüfschild (Motor) muss mit der Temperaturklasse des möglicherweise auftretenden brennbaren Gases übereinstimmen.
- Montage und elektrische Installation darf nur durch geeignetes Fachpersonal, das die **einschlägigen Vorschriften** beachtet, vorgenommen werden!
- Jedem Motor muss ein Motorschutzschalter vorgeschaltet sein. Beachten Sie hierzu die Angaben des Motorherstellers.
- Wicklungsüberwachung durch Kaltleiter für Abschaltung am Umrichter. Zur Schutzeinrichtung wird ein Auslösegerät mit Kennzeichen II (2) G benötigt.
- Bei Drehzahlsteuerung durch Frequenzumrichter ist sicherzustellen, dass die max. zul. Drehzahl nicht durch eine Fehlfunktion des Frequenzumrichters überschritten wird.
- Bei Betrieb mit Frequenzumrichter ist eine Übermodulation nicht zulässig. Lüfterrad kann bersten - **Lebensgefahr!**
- Bezüglich Drehzahlregelung mit Frequenzumrichter sind die Sicherheitshinweise und Empfehlungen gemäß der Betriebsanleitung des Motorherstellers einzuhalten. Dies gilt auch in Bezug auf Motoreinbau, elektrischen Anschluss und Wartung.
- Beachten Sie die Einbau- und Sicherheitshinweise zu den verschiedenen Ventilatorbauformen. Nichtbeachtung oder Missbrauch kann zu körperlichen Schäden oder Beschädigung des Ventilators und zur Explosion einer zündfähigen Gas-Luftatmosphäre führen - **Lebensgefahr.**
- Beachten Sie die Hinweise in der Betriebsanleitung des Motorherstellers, die Bestandteil des Lieferumfangs ist.
- Wird der Ventilator frei ansaugend oder frei ausblasend eingesetzt, ist zu prüfen, ob die Sicherheitsabstände gemäß **DIN EN ISO 13857 / EN 60529** eingehalten werden.
- Die Einhaltung der Norm DIN EN ISO 13857 / EN 60529 bezieht sich nur auf den montierten Berührschutz, sofern dieser zum Lieferumfang gehört.
- Achten Sie insbesondere saugseitig auf ausreichend bemessenen Sicherheitsabstand, da durch die Sogwirkung des Ventilators Kleidung, Gliedmaßen oder bei größeren Ventilatoren auch Personen angesaugt werden können.

- Wenn durch die Geräte- oder Anlagenkonstruktion das Ansaugen oder Hereinfallen größerer Teile in den Laufradbereich nicht ausgeschlossen werden kann - **Gefahr der Explosion einer zündfähigen Gas-Luftatmosphäre**  
- ist saugseitig ein Schutzgitter zwingend erforderlich.
- Blockieren oder Abbremsen des Ventilators durch z. B. Hineinstecken von Gegenständen ist untersagt. Dies führt zu heißen Oberflächen und Beschädigungen am Laufrad.
- Ein Restrisiko durch Fehlverhalten, Fehlfunktion oder Einwirken höherer Gewalt beim Betreiben des Laufrades kann nicht völlig ausgeschlossen werden. Der Planer oder Erbauer der Anlage muss durch geeignete Sicherheitsmaßnahmen nach DIN EN ISO 13857 / EN 60529, z. B. Schutzeinrichtungen, verhindern, dass eine Gefährdungssituation entstehen kann.
- Diese Montageanleitung ist Teil des Produktes und als solche zugänglich aufzubewahren.



## Transport, Lagerung

### Bei der Handhabung Sicherheitsschuhe und Schutzhandschuhe benutzen!

- Radiallaufräder oder Einbauventilatoren ER..C werden in der Regel auf Europaletten geliefert und können mittels Hubwagen transportiert werden.
- Bei Transport mit Hebezeugen:
  - **Bauform RH..C ohne Motor:** Hebeband mit ausreichender Traglast um eine Laufradschaufel herumlegen. Beachten Sie die Gewichtsangabe auf dem Typenschild (Rückseite der Laufradbodenscheibe). Verwenden Sie nur ein Hebeband, das geeignet ist, scharfkantige Lasten zu tragen.
  - **Bauform ER..C:** Ventilatoreinheit darf nur mit geeignetem Hebezeug (Lasttraverse) angehoben und transportiert werden. Auf ausreichende Seil- bzw. Kettenlänge ist zu achten.
  - **Achtung: Anordnung der Lasttraverse quer zur Motorachse. Auf ausreichende Breite der Lasttraverse achten. Kette bzw. Seil darf das Lüfterrad beim Anheben nicht berühren!** Stellen Sie sich auf keinen Fall unter den schwelenden Ventilator, da im Falle eines Defektes am Transportmittel Lebensgefahr besteht. Beachten Sie unbedingt immer die Gewichtsangaben auf dem Ventilator-Typenschild und die zul. Traglasten des Transportmittels.
- Vermeiden Sie Schläge und Stöße, besonders bei auf Geräten aufgebauten Ventilatoren.
- Bei Beschädigungen umgehend den Spediteur benachrichtigen.
- Lagern Sie den Ventilator in trockener, staub- und schwingungsfreier Umgebung.
- Vermeiden Sie zu lange Lagerzeiträume. Beachten Sie hierzu die Hinweise des Motorherstellers.



## Laufradeinbau

### Laufräder mit Festnabe

- Das Laufrad wird mittels Festnabe mit dem Wellenende des Antriebsmotors verbunden.
- Montage: Alle blanken Oberflächen (Wellenende, Nabengrundbohrung) leicht befestigen. Laufrad mit Nabe (1) bis auf Wellenschulter (2) aufziehen (Übergangspassung). Bei entsprechendem Gewicht mit Hebezeug sichern. Axiale Wellensicherung mittels Schraube (3) und Scheibe (4) vorsehen. Anzugsmomente nach Tabelle einhalten. Die Schraube (3) ist mit einer Sicherungsscheibe (z. B. Sperrkant- oder Kontaktsscheibe) zu sichern. Bei Motoren ab BG132 (WellenØ 38) ist nach Norm EN 14986 eine Sonderscheibe mit Schrauben (5) zur zusätzlichen Sicherung angebracht. Anzugsmomente nach Tabelle einhalten.
- Demontage: Axiale Schraubensicherung lösen und Laufrad mit Nabe mittels geeigneter Abziehvorrichtung abziehen (bei entsprechendem Gewicht mit Hebezeug sichern). Bei Motoren ab BG132 muss die zusätzliche axiale Wellensicherung (5) ebenfalls gelöst werden.

- If, due to the device or the system design, it cannot be excluded that large parts could be sucked into or fall into the impeller area - **danger of explosion of an ignitable gas-air atmosphere** - a suction-side guard grille is absolutely required.
- Blocking or braking the fan by, say, pushing objects into it is forbidden. This leads to heated surfaces and damage to the impeller.
- Residual risk due to inappropriate behavior, malfunction, or influence through acts of God during operation of the impeller cannot be completely excluded. The system planner or constructor must prevent the emergence of a hazardous situation through suitable safety measures in accordance with DIN EN ISO 13857 / EN 60529, e.g., through protective devices.
- These assembly instructions are part of the product and, as such, are to be kept accessible at all times.



## Transport, storage

### Wear safety shoes and gloves for handling!



- Centrifugal impellers and ER..C plug fans are generally delivered on Euro palettes and can be transported using lift trucks.
- When transporting using hoists/cranes:
  - **RH..C design without motor:** Wrap an impeller blade using a sling band with a sufficient amount of ultimate load. Observe the weight data on the identification plate (back of the impeller base plate). Use only sling bands that are suitable for carrying sharp-edged loads.
  - **ER..C design:** Fan unit may only be lifted and transported using a suitable hoisting device (load spreader). Ensure there is sufficient cable or chain length.
  - **Caution: Arrange the lifting beam transverse to the motor axis. Ensure that the lifting beam is sufficiently wide. Chain or cable must not touch the fan impeller during lifting!** Never stand under the swinging fan, since life can be at risk in the event of a defect in the transporter. Make sure that the weight information on the fan rating plate and the permissible loads of the transporter are always observed.
- Avoid impacts and collisions, especially on fans set-up on devices.
- In the event of damage inform the carrying agent immediately.
- Store the fan in a dry, dust- and vibration-free environment.
- Avoid excessive storage times. Please refer to the manufacturer's motor information on this.



## Installing the impeller


### Impellers with fixed hub

- The impeller is connected to the shaft end of the drive motor using a fixed hub.
- Installation: Lightly lubricate all bare surfaces (shaft ends, hub holes). Pull the impeller with the hub (1) up to the shaft shoulder (5) (transitional fit). Secure with the hoisting device with corresponding weight. Secure the axial shaft-locking device using the screw (3) and washer (4). Maintain the torque in accordance with the table. The screw (3) is to be secured using a locking washer (e.g. square taper washer or contact washer). For motors starting from BG132 (shaft Ø 38), a special washer with screws (5) is to be attached as an additional safeguard in accordance with EN 14986 standard. Maintain the torque in accordance with the table.
- Disassembly: Release the axial screw connection and pull off the impeller with the hub using a suitable pulling unit (secure with hoisting device at the corresponding weight). For motors starting from BG132, the additional axial shaft-locking device (5) must be released also.




FK 8.8	M4	M5	M6	M8	M10	M12
MA	2,8 Nm	5,5 Nm	9,5 Nm	23 Nm	46 Nm	79 Nm

- Bei Einhaltung der Werkstoffpaarung müssen folgende Mindestspalte eingehalten werden: zwischen rotierenden und stehenden Teilen (Laufraddeckscheibe / Einström-düse bzw. Druckentnahmenippel) darf der Mindestspalt (s) nicht kleiner als 1 % des maßgeblichen Kontakt durchmessers, aber nicht weniger als 2 mm betragen.



SC 8.8	M4	M5	M6	M8	M10	M12
MA	2,8 Nm	5,5 Nm	9.5 Nm	23 Nm	46 Nm	79 Nm

- The following minimum gap must be maintained during compliance of materials mating: between the rotating and stationary parts (impeller shroud / inlet ring or pressure release nipple), the minimum gap (s) must not be smaller than 1 % of the relevant contact diameter, but must not be less than 2 mm.



- Vor- bzw. nachgeschaltete Bauteile oder solche, die unmittelbar im Luftstrom liegen, dürfen keine ungeschützten Aluminium- oder Stahloberflächen aufweisen. Erforderlich ist eine Lackierung oder Kunststoffbeschichtung, welche mindestens Gitterschnitt-Kennwert 2 nach DIN EN ISO 2409 erfüllt. Der Oberflächenschutz soll verhindern, dass es zur Bildung von Rost oder Ablagerung von Eisenoxyd oder kleineren Rostpartikeln kommt, welche in Verbindung mit Aluminium und dem Auftreffen von Partikeln mit hoher Luftgeschwindigkeit zu einer chemischen Reaktion (aluminiotherm. Reaktion) und somit zur Zündung einer explosionsfähigen Gas-Luftatmosphäre führt.



### Elektrischer Anschluss

- Darf nur von technisch ausgebildetem Fachpersonal (DIN EN 50 110, IEC 364) vorgenommen werden.
- Nur Kabel verwenden, die eine dauerhafte Dichtigkeit in Kabelverschraubungen gewährleisten (druckfest-formstabil, zentrisch-runder Mantel; z. B. mittels Zwickelfüllung)!
- Der Ventilator darf nur an Stromkreise angeschlossen werden, die mit einem allpolig trennenden Schalter abschaltbar sind.
- Beachten Sie unbedingt die Sicherheits- und Inbetriebnahmehinweise des Motorherstellers, sowie die im Motor-Klemmenkasten befindlichen Schaltbilder.
- Vor dem elektrischen Anschluss des Motors die Anschlussdaten mit den Angaben auf dem Motortypenschild vergleichen.



### Geräteaufstellung

#### Bei der Handhabung Sicherheitsschuhe und Schutzhandschuhe benutzen!

- Sicherheitshinweise beachten!
- Um die Übertragung störender Schwingungen zu vermeiden, wird eine Körperschallentkopplung des kompletten Einbauventilators empfohlen. (Feder- bzw. Dämpfungselemente sind nicht Bestandteil des serienmäßigen Lieferumfangs). Die Zuordnung der Abstandmaße der Federdämpfer, je nachdem, ob der Ventilator mit oder ohne Zubehör ausgestattet ist, kann unserer Homepage



### Electrical connection

- May only be undertaken by technically trained personnel (DIN EN 50 110, IEC 364).
- Only use lines which can guarantee a permanent seal around the cable glands (pressure-resistant, dimensionally-stable, round-centred jacket; e.g. by means of gusset filling)!
- Connect fan only to electrical circuits that can be disconnected with an all-pole isolating switch.
- Ensure that attention is paid to the motor manufacturer's safety and commissioning information and the circuit diagrams in the motor terminal box.
- Before making the electrical motor connections, compare the connection specifications with the specifications on the motor identification plate.



### Setting up the unit

#### Wear safety shoes and gloves for handling!

- Observe the safety information!
- In order to avoid transmitting disturbing vibrations, it is recommended that a means of decoupling the structure borne noise of the complete built-in fan should be used. (Spring or attenuation components are not part of the standard supply). The allocation of the distance between the spring suspensions, depending on whether the fan is fitted with accessories or not, can be found on our homepage at [www.ziehl-abegg.de](http://www.ziehl-abegg.de) in the Download section - Ventilation and Control Technology.

- unter [www.ziehl-abegg.de](http://www.ziehl-abegg.de) im Bereich Download - Luft- und Regeltechnik entnommen werden.
- Achtung: Alle Auflagepunkte müssen betriebssicher mit dem Fundament verbunden sein. Bei nicht ausreichender Befestigung besteht Gefahr durch Kippen des Ventilators.**
  - Auf ausreichende saug- und druckseitige Abstände achten.
  - Aufstellung im Freien nur, wenn in den Bestellunterlagen ausdrücklich vermerkt und bestätigt. Bei längeren Stillstandszeiten in feuchter Umgebung besteht die Gefahr von Lagerschäden. Korrosion durch entsprechende Schutzmaßnahmen vermeiden. Eine Überdachung ist erforderlich.
  - Eigenmächtige Veränderungen/Umbauten am Ventilator sind nicht zulässig - Sicherheitsrisiko.
  - Werden Gefährdungen durch Blitzschlag festgestellt, müssen die Anlagen durch geeignete Blitzschutzmaßnahmen geschützt werden.
  - Anlagen müssen in ausreichendem Sicherheitsabstand zu Sendeanlagen oder durch geeignete Abschirmung geschützt werden.
  - ER-Ventilatoren dürfen nur in Einbaulage H (Ventilator stehend, Motorwelle horizontal) betrieben werden!
  - Das Demontieren bzw. das Anbringen von Bauteilen am Ventilator bzw. Laufrad führt zum Erlöschen der Garantieleistung! Ausnahme: Der Klemmkastendeckel darf zum Auflegen der Anschlusskabel von technisch ausgebildetem Fachpersonal (DIN EN 50110, IEC 364) geöffnet werden. Am Klemmkasten dürfen geeignete Kabelverschraubungen angebracht werden.

#### Zubehör:

- Als Zubehör können Schutzgitter, Federdämpfer und Gewebekompensatoren bezogen werden. Beim Einbau bzw. Anbau dieser Elemente ist der Anlagebauer dafür verantwortlich die Zubehörteile zu erden.



## Betriebsbedingungen

- Beachten Sie die Angaben des Motorherstellers.
- Ein Überschreiten der max. zul. Betriebsdrehzahl (Ventilator-/Laufrad-Typenschild) ist nicht zulässig, siehe Sicherheitshinweise. Die max. zulässige Betriebsdrehzahl gilt für Dauerbetrieb S1. Hohe Schalthäufigkeit ist zu vermeiden. Anlauf über Y/D-Schaltung. Ventilator nicht im Resonanzbereich des Laufrades betreiben - Gefahr durch Dauerbruch.
- Bei Betrieb mit Frequenzumrichter ist eine Übermodulation nicht zulässig. Lüfterrad kann bersten - **Lebensgefahr!**
- A-bewerteter Schallleistungspegel größer 80dB(A) möglich, siehe Produktkatalog.



## Inbetriebnahme

- Vor Erstinbetriebnahme prüfen:
  - Hinweise des Motorherstellers zur Inbetriebnahme berücksichtigt?
  - Ist der Motorschutz richtig eingestellt? Polumschaltbare Motoren benötigen für jede Polzahl einen eigenen Schalter. Bei Dreieck-Schaltung muss ein Überlastschutz mit Phasenausfallschutz vorgesehen werden.
  - Einbau und elektrische Installation fachgerecht abgeschlossen?
  - Eventuell vorhandene Montagerückstände und Fremdkörper aus dem Laufrad- und Ansaugbereich entfernt?
- Der Ventilator ist nach dem Einbau auf mechanische Schwingungen zu überprüfen. Ist die Schwingstärke des Ventilators größer als 2,8 mm/s (gemessen am Lagerschild des laufseitigen Motorlagers), muss das Laufrad von Fachpersonal überprüft und gegebenenfalls nachgewuchtet werden.
- Inbetriebnahme darf erst erfolgen, wenn alle Sicherheitshinweise überprüft und eine Gefährdung ausgeschlossen ist.
  - Stromaufnahme prüfen! **Ist die Stromaufnahme höher als auf dem Motor-Leistungsschild angegeben, ist der Ventilator sofort außer Betrieb zu setzen.**
  - Drehrichtung kontrollieren (Drehrichtungspfeil auf Laufradbodenscheibe bzw. am Ventilatorgehäuse)
  - Auf ruhigen, schwingungsarmen Lauf achten.

- Caution: All contact points must be fixed securely to the base. If the fixing is inadequate there is a risk of the fan overturning.**
- Ensure adequate clearance on suction and pressure sides.

- Erect in the open air only if this is expressly mentioned and confirmed in the ordering information. There is a risk of damage to the bearings if the fan remains stopped in a moist environment. Avoid corrosion by suitable protective measures. Roofing is required.*
- Modifications/conversions to the fan undertaken by the operator are not permissible - safety hazard.*
- If hazards from lightning strikes have been ascertained, the system must be protected through the use of suitable lightning protection measures.*
- Systems must be sufficiently separated from transmitting installations or be protected through suitable shielding.*
- ER fans may only be operated in installation position H (fan upright, motor shaft horizontal)!*
- Dismantling and attaching components to the fan or impeller results in expiration of the warranty! Exception: the terminal-box cover may be opened so that technically trained qualified-persons (DIN EN 50110, IEC 364) can attach the connection cable. Suitable threaded cable-connections may be attached to the terminal box.*

#### Accessories:

- Guard grills, spring suspensions, and fabric expansion joints can be ordered as accessories. During the installation or addition of these elements, the system constructor is responsible for grounding the accessory components.



## Operating conditions

- Observe the motor manufacturer's instructions.
- Exceeding the max. permissible operating speed (fan / impeller rating plate) is not permissible; see safety instructions. The max. permissible operating speed applies to continuous operation S1. High switching frequencies are to be avoided. Start-up via Y/D connection. Do not operate the fan in the resonance range of the impeller - danger through fatigue fracture.
- When in operation with a frequency converter, no over-modulation is allowed. The fan wheel may burst – **danger to life!**
- A-rated sound power levels of over 80 dB(A) are possible, see product catalogue.



## Start-up

- Before first-time start-up, check the following:
  - Account has been taken of the motor manufacturer's information?
  - Ensure that the motor protection is correctly set? Pole-changing motors need a separate switch for each number of poles. An excess-current switch with phase monitor must be provided for delta connections.
  - Installation and electrical connection have been properly completed?
  - All leftover installation materials and other foreign materials have been removed from the fan cavity.
- After installation, check the fan for mechanical oscillations. If the amount of fan oscillation is larger than 2.8 mm/s, (measured on the end plate of the impeller side of the motor bearing), the impeller must be examined by specialists and, if necessary, rebalanced.
- Commissioning may only take place if all safety instructions have been checked and danger can be excluded.
  - Check the current consumption! **If the current consumption is higher than that stated on the motor rating plate, the fan must be disconnected immediately.**
  - Check the direction of rotation (the rotation direction arrow is on the impeller base plate or on the fan housing)
  - Watch out for smooth, vibration free motion.



## Instandhaltung und Wartung

- Der Anlagenbauer muss eine leichte Zugänglichkeit für Reinigungs- und Inspektionsarbeiten ermöglichen.
- **Bei der Handhabung Sicherheitsschuhe und Schutzhandschuhe benutzen!**
- Überprüfung des Ventilators auf mechanische Schwingungen gemäß ISO 14694. Empfehlung: alle 6 Monate. Die max. zul. Schwingstärke beträgt 2,8 mm/s (gemessen am Lagerschild des laufradseitigen Motorlagers, oder gem. den speziellen Vereinbarungen mit dem Kunden).
- Je nach Einsatzbereich und Fördermedium unterliegen Laufrad und Gehäuse einem natürlichem Verschleiß. Ablagerungen am Laufrad können zur Unwucht und damit zu Schäden (Gefahr eines Dauerbruchs) führen.
  - Laufrad kann bersten - Lebensgefahr!
  - Beachten Sie die Angaben des Motorherstellers zur Instandhaltung und Wartung.
- Instandsetzungsarbeiten nur durch ausgebildetes Fachpersonal vornehmen lassen.
- **Bei allen Instandsetzungs- und Wartungsarbeiten:**
  - Sicherheits- und Arbeitsvorschriften (DIN EN 50 110, IEC 364) beachten.
  - Ventilatorlaufrad steht still!
  - Stromkreis unterbrochen und gegen Wiedereinschalten gesichert.
  - Bei Betrieb über Frequenzumrichter Wartezeit nach dem Freischalten beachten - siehe Betriebsanleitung des Herstellers bezüglich Entladungszeit der Kondensatoren.
  - Spannungsfreiheit feststellen.
  - Keine Wartungsarbeiten am laufenden Ventilator!
  - Halten Sie die Luftwege des Ventilators frei - Gefahr durch herausfliegende Gegenstände!
  - Flügel nicht verbiegen - Unwucht!
  - Achten Sie auf untypische Laufgeräusche!
- Die Betriebsmittel in explosionsgeschützter Ausführung dürfen weder geöffnet noch repariert werden. Ein Lagerwechsel von Kunden oder vom normalen Servicefachmann ist ebenfalls nicht zugelassen.
- Nach Laufraddemontage und Wiedermontage ist es zwingend erforderlich, die gesamte rotierende Einheit nach DIN ISO 1940-1 neu auszuwuchten.
- Bei allen anderen Schäden (z.B. Wicklungsschäden) wenden Sie sich bitte an unsere Serviceabteilung.
- Laufrad, insbesondere Schweißnähte, auf eventuelle Rissbildung überprüfen.
- ZIEHL-ABEGG Atex-Ventilatoren / Motoren sind ganz oder teilweise mit antistatischer, ableitfähiger Lackierung oder Beschichtung versehen. Ein Nachlackieren kann zu gefährlichen statischen Aufladungen führen und ist daher nicht zulässig.



## Reinigung

- Regelmäßige Inspektion, ggf. mit Reinigung erforderlich um Unwucht durch Verschmutzung zu vermeiden.
  - Durchströmungsbereich des Ventilators säubern.
- Achten Sie auf schwingungssachen Lauf.
- Wartungsintervalle je nach Verschmutzungsgrad des Laufrades.
- Der komplette Ventilator darf mit einem feuchten Putztuch gereinigt werden.
- Zur Reinigung dürfen keine aggressiven, lacklösenden Reinigungsmittel verwendet werden.
- **Verwenden Sie keinesfalls einen Hochdruckreiniger oder Strahlwasser zur Reinigung - schon gar nicht bei laufendem Ventilator.**
- Wenn Wasser in den Motor eingedrungen ist:
  - Vor erneutem Einsatz Wicklung des Motors trocknen.
  - Exgeschützte Motoren dürfen weder geöffnet noch repariert werden. Wenn ein Exgeschützter Motor Fehler aufweist, ist er unbedingt zum Hersteller / Lieferant zurückzuschicken, und ein neuer Ersatzmotor ist anzufordern.
- **Nassreinigung unter Spannung kann zum Stromschlag führen - Lebensgefahr!**



## Repairs and maintenance

- The system constructor must enable easy access for cleaning and inspection work.
- **Wear safety shoes and gloves for handling!**
- Check the fan for mechanical oscillations in accordance with ISO 14694. Recommendation: every six months. The max. permissible vibration severity is 2.8 mm/s (measured on the end shield of the impeller side of the motor bearing or according to the special service agreement with the customer).
- Depending on the use and the medium in which it operates, the impeller and housing are subject to normal wear. Deposits on the impeller can lead to imbalance and hence to damage (risk of fatigue fracture)
  - The impeller can disintegrate - lethal hazard!
  - Observe the motor manufacturer's instructions concerning maintenance and service.
- Allow maintenance work to be carried out by trained specialists only.
- **For all repair and maintenance work:**
  - Observe the safety and labour regulations (DIN EN 50 110, IEC 364).
  - The fan impeller stopped!
  - Open the electrical circuit and secure against being switched back on.
  - When operating by means of frequency converter, ensure that the waiting time is maintained after safety disconnection - see manufacturer's operating instructions regarding capacitor discharge time.
  - Verify the absence of voltage.
  - No maintenance work at running fan!
  - Keep the airways of the fan free- danger because of objects dropping out!
  - Do not deform the blades - out-of balance!
  - Take note of abnormal operating noise!
- The equipment in explosion-proof version must neither be opened nor repaired. Bearing changes are also not permitted by the customer or normal service technician.
- After dismantling and reinstalling an impeller, the entire rotating unit must be rebalanced in accordance with DIN ISO 21940-11
- Please contact our service department about any other damage (e.g. winding damage).
- Check the impeller, in particular the weld-seams, for possible cracks.
- ZIEHL-ABEGG Atex-fans / motors are completely or partly covered by antistatic painting or coating, which is able to derive electric charges. A repaint may lead to dangerous static charges and is therefore not allowed.



## Cleaning

- Regular inspection, and cleaning is necessary to prevent imbalance due to ingress of dirt.
  - Clean the fans' flow area.
- Watch out for vibration free motion.
- Maintenance interval in accordance with the degree of contamination of the impeller!
- You can clean the entire fan with a moist cloth.
- Do not use any aggressive, paint solvent cleaning agents when cleaning.
- **Never use a high-pressure cleaner or water-spray for cleaning - particularly when the ventilator is running.**
- If water enters the motor:
  - Dry off the motor winding before using it again.
  - Explosion-proof motors must neither be opened nor repaired. If an explosion-proof motor has defects, it is absolutely essential to send it back to the manufacturer / supplier requesting a new replacement motor.
- **Wet cleaning under voltage may lead to an electric shock - danger to life!**

## **Hersteller**

Unsere Produkte sind nach den einschlägigen internationalen Vorschriften gefertigt (Auflistung und Ausgabestände siehe EG-Einbauerklarung und EU-Konformitätserklärung). Haben Sie Fragen zur Verwendung unserer Produkte oder planen Sie spezielle Anwendungen, wenden Sie sich bitte an:

**ZIEHL-ABEGG SE**  
**Heinz-Ziehl-Straße**  
**D-74653 Künzelsau**  
**Tel. 07940/16-0**  
**Fax 07940/16-300**  
**info@ziehl-abegg.de**

### **Serviceadresse**

Länderspezifische Serviceadressen siehe Homepage unter  
[www.ziehl-abegg.com](http://www.ziehl-abegg.com)

## **Manufacturer:**

*Our products are manufactured in compliance with applicable international standards and regulations (listing and relevant version see EC Declaration of Incorporation and EC Declaration of Conformity).*

*If you have any questions about how to use our products or if you are planning special applications, please contact:*

**ZIEHL-ABEGG SE**  
**Heinz-Ziehl-Straße**  
**D-74653 Künzelsau**  
**Phone 07940/16-0**  
**Fax 07940/16-300**  
**info@ziehl-abegg.de**

### **Service address**

*Please refer to the homepage at [www.ziehl-abegg.com](http://www.ziehl-abegg.com) for a list of our subsidiaries worldwide.*

# EC Declaration of Incorporation

as defined by the EC Machinery Directive 2006/42/EC, Annex II B

- Translation -  
(english)

ZA87ex-GB 1831 Index 006

## The design of the incomplete machine:

- External rotor motor for explosion-hazardous areas, type of protection "nA" / "ec" or "e" / "eb" MK..
- Axial fan for explosion-hazardous areas, type of protection "c" / "h", with external rotor motor for explosion-hazardous areas, type of protection "nA" / "ec" or "e" / "eb" FB..
- Centrifugal fan for potentially explosive areas, ignition protection class "c" / "h" with external rotor motor, ignition protection class "nA" / "ec" or ignition protection class "e" / "eb" for RE.., RH..
- Centrifugal fan for explosion-hazardous areas, type of protection "c" / "h", with internal rotor motor for explosion-hazardous areas, type of protection "tc" RH.., GR..
- Centrifugal fan for explosion-hazardous areas, type of protection "c" / "h", with internal rotor motor for explosion-hazardous areas, type of protection "d" / "db" ER..
- Centrifugal fan for explosion-hazardous areas, type of protection "c" / "h", with internal rotor motor for explosion-hazardous areas, type of protection "nA" / "ec" GR.., RG..
- Centrifugal fan for explosion-hazardous areas, type of protection "c" / "h", with internal rotor motor for explosion-hazardous areas, type of protection "tc" GR.., RG..

## Motor type:

- Asynchronous external or internal rotor motor
- Electronically commutated internal rotor motor (with integrated EC controller)

**complies with the requirements in Appendix I, Articles 1.1.2, 1.1.5, 1.4.1, 1.5.1, 1.5.7 in EC Machinery Directive 2006/42/EC.**

## The manufacturer is the

**ZIEHL-ABEGG SE  
Heinz-Ziehl-Strasse  
D-74653 Künzelsau**

## The following harmonised standards have been used:

EN 1127-1:2011	Explosive atmospheres - Explosion protection - Part 1: Fundamentals and methodology
EN 60204-1:2006	Safety of machinery; electrical equipment of machines; Part 1: General requirements
EN ISO 12100:2010	Safety of machinery; basic concepts, general principles for design
EN ISO 13857:2008	Safety of machinery; safety distances to prevent danger zones being reached by the upper limbs
Note:	The maintenance of the EN1-ISO 13857:2008 relates only to the installed accidental contact protection, -2-provided that it is part of the scope of delivery.

The specific technical documentation in accordance with Appendix VII B has been written and is available in its entirety.

The person authorised for compiling the specific technical documentation is: Dr. W. Angelis, address see above.

The specific documentation will be transmitted to the official authorities on justified request. The transmission can be electronic, on data carriers or on paper. All industrial property rights remain with the above-mentioned manufacturer.

**It is prohibited to commission this incomplete machine until it has been secured that the machine into which it was incorporated complies with the stipulations of the EC Machinery Directive.**

Künzelsau, 01.08.2018  
(location, date of issue)

ZIEHL-ABEGG SE  
Dr. W. Angelis  
Technical Director Air Movement Division  
(name, function)

i.v. W. Angelis

(Signature)

ZIEHL-ABEGG SE  
Dr. D. Kappel  
Deputy Head of Electrical Systems  
(name, function)

i.v. David Kappel

(Signature)

# EU declaration of conformity

- Translation -  
(english)

ZA75ex-GB 1831 Index 018

**Manufacturer:** ZIEHL-ABEGG SE  
Heinz-Ziehl-Straße  
74653 Künzelsau  
Germany

The manufacturer is solely responsible for issuance of the declaration of conformity.

The products:

- External rotor motor MK..
  - with EC type approval certificates PTB 08 ATEX 3060, PTB 08 ATEX 3061, PTB 08 ATEX 3062 as electrical equipment for potentially explosive areas, ignition protection class "e" / "eb"
    - as electrical operating equipment for potentially explosive areas, ignition protection class "nA" / "ec"
- Internal rotor motor
  - with EC type approval certificate or EC declaration of conformity BG080\_U58\_BVS\_13\_ATEX\_E\_128\_X, BG090\_U58\_BVS\_13\_ATEX\_E\_098\_X, BG100\_U58\_BVS\_13\_ATEX\_E\_127\_X, BG112\_U58\_BVS\_13\_ATEX\_E\_126\_X, BG132\_U58\_BVS\_13\_ATEX\_E\_099\_X, BG160\_U58\_BVS\_13\_ATEX\_E\_019\_X, BG180\_U58\_BVS\_13\_ATEX\_E\_017\_X, BG200\_U58\_BVS\_13\_ATEX\_E\_012\_X, BG225\_U58\_BVS\_12\_ATEX\_E\_103\_X, BG250\_U58\_BVS\_11\_ATEX\_E\_045\_X and PTB 12 ATEX 3016 as electrical operating equipment for potentially explosive areas, ignition protection class "d" / "db", "de" / "db eb", "tb" and "tc"
    - with EC type approval certificate or EC declaration of conformity PTB 05 ATEX 3006, PTB 12 ATEX 3014 and BVS 14 ATEX E 081 as electrical operating equipment for potentially explosive areas, ignition protection class "nA" / "ec"
    - with EC type approval certificates or EC declarations of conformity Baseefa 13 ATEX 0016 X, Baseefa 13 ATEX 0079 X, Baseefa 13 ATEX 0288 X, Baseefa 14 ATEX 0208 X as electrical operating equipment for potentially explosive areas, ignition protection class "d", "db", "de", "db eb" and "tb"
    - with EC type approval certificate or EC declaration of conformity CNEX 17 ATEX 0004 X as electrical operating equipment for potentially explosive areas, ignition protection class "db" and "tb"
- Axial fan FB.. of Group II, Device Category 2G
  - with EC model test certificate ZELM 04 ATEX 0236 X, with protection type "c" for conveying explosive gas atmospheres of Group IIB for zone 1 and zone 2, with external rotor motor MK.. for explosive areas, protection type "e" / "eb".
- Group II, 3G appliance category FB.. axial fan
  - type of protection "c" / "h" for the conveyance of potentially explosive, group IIB for zone 2 gas atmospheres; type of protection "nA" / "ec" with an external rotor motor MK.. for explosion-hazardous areas
- Group II, 2G appliance category RE.., RH.. centrifugal fans
  - type of protection "c" / "h" for the conveyance of potentially explosive, group IIB gas atmospheres for zones 1 and 2, with an external rotor motor MK.. with EC type approval certificates PTB 08 ATEX 3060, PTB 08 ATEX 3061, PTB 08 ATEX 3062 for explosion-hazardous areas, type of protection "e" / "eb"
- Group II, 3G appliance category RE.., RH.. centrifugal fans
  - type of protection "c" / "h" for the conveyance of potentially explosive, group IIB gas atmospheres for zone 2, with an external rotor motor MK.. for explosion-hazardous areas, type of protection "nA" / "ec".
- Group II, 3D appliance category RE.., RH.., GR.. centrifugal fans
  - type of protection "c" / "h" for the conveyance of potentially explosive, group IIIB dust atmospheres for zone 22, with an EC-internal rotor motor MK.. for explosion-hazardous areas, type of protection "tc"
- Group II, 2G appliance category ER.. centrifugal fans
  - type of protection "c" / "h" for the conveyance of potentially explosive, group IIB gas atmospheres for zone 1 and zone 2, with an internal rotor motor for explosion-hazardous areas, type of protection "d" / "db"

- Group II, 3G equipment category GR.., RG.. centrifugal fans  
ignition protection class "c" / "h" for conveyance of explosive, group IIB gas atmospheres for zone 2, with internal rotor motor for potentially explosive areas, ignition protection class "nA" / "ec"
- Group II, 3D appliance category GR.., RG.. centrifugal fans  
type of protection "c" / "h" for the conveyance of potentially explosive, group IIIB dust atmospheres for zone 22, with an internal rotor motor for explosion-hazardous areas, type of protection "tc"

**These products are developed, designed and manufactured according to the following directives:**

- EMC Directive 2014/30/EU
- ATEX Directive 2014/34/EU

**The following harmonised standards have been used:**

EN 61000-6-3:2007	EN 60079-31:2014
EN 61000-6-2:2005	EN 1127-1:2011
EN 60079-0:2012+A11:2013	EN 80079-36:2017
EN 60079-7:2015	EN 80079-37:2016
EN 60079-15:2010	

- **The following standard is in use for FB axial fans**

EN14986:2017      Design of fans working in potentially explosive atmospheres  
 Note:                The manufacturer of the plant is responsible for the complete compliance with the standard EN14986:2017 as well as for the compliance with the combinations of material and the minimum gap.  
 Compliance with the EN14986:2017 standard relates only to the installed protective grille and the inlet nozzle, if these are included in the scope of supply.

- **The following standard is in use for RE.., RH.., ER.., GR.. and RG.. centrifugal fans:**

EN14986:2017      Design of fans working in potentially explosive atmospheres  
 Note:                The manufacturer of the plant is responsible for the complete compliance with the standard EN14986:2017 as well as for the compliance with the combinations of material and the minimum gap.  
 Also applicable to ER:  
 Compliance with the EN14986:2017 standard relates only to the installed protective grille and the inlet nozzle, if these are included in the scope of supply.

**Name , address and identification number of the notified location:**

- For external rotor motors MK :  
**Physikalisch-Technische Bundesanstalt (PTB)**  
**Bundesallee 100 , D - 38116 Braunschweig , identification number 0102**
- For axial fans FB :  
**ZELM Ex E.K. - Testing and Certification Body**  
**Siekgraben 56 , D - 38124 Braunschweig , identification number 0820**
- For centrifugal fans RE .. , RH .. , ER .. :  
**Federal Institute for Materials Research and Testing ( BAM )**  
**Unter den Eichen 87 , D - 12205 Berlin , identification number 0589**

Compliance with the EMC Directive 2014/30 / EU refers only to those products when they are connected by mounting / operating instructions . If these products are integrated into a system or supplemented with other components (eg. sensing controls) and operated , the manufacturer or operator is responsible of the overall system for compliance with the EMC Directive 2014/30 / EU .

Künzelsau, 01.08.2018  
(location, date of issue)

ZIEHL-ABEGG SE  
Dr. W. Angelis  
Technical Director Air Movement Division  
(name, function)

i.v. W. Angelis

(Signature)

ZIEHL-ABEGG SE  
Dr. D. Kappel  
Deputy Head of Electrical Systems  
(name, function)

i.v. David Kappel

(Signature)